

A PARTY PLEASING



RENTAL

SNO-KONE MACHINE

38 Route 10 Westbound
East Hanover, NJ 07936
973/887-7264 fax 973/887-0686
www.aPartyPleasing.com

Machine Operation:

1. Start the motor and fill the gooseneck with ice cubes or block ice broken into pieces 3" to 4" in size. Fill to about an inch from the top. The larger the ice chunks, the better the snow!
2. Push the pusher handle down to press the ice against the cutterhead. A firm even pressure is all that is required, but sometimes you will find it better to relieve the pressure two or three times on the way down. This lets the ice rearrange itself.
3. **DO NOT FORCE THE HANDLE!!!!** Too much pressure will stall the motor.
4. When too much pressure is necessary, relieve the handle and the re-apply pressure. Too much pressure will cause the ice to come out coarse, too little pressure and the ice will be mushy.

CAUTION:

- Do not let any metal get down into the gooseneck. It will ruin the blades.
- Never put any fingers or any object into the shaver body while the motor is running. Disregard for these instructions and careless handling can result in accidents and/or injury.
- If you experience any problems with this equipment, please cease operation and contact us at the number above.

CLEANING

- Always unplug the machine before cleaning.
- Wipe all surfaces clean before returning equipment to avoid **ADDITIONAL CLEANING CHARGES.**